




# Quick Start Guide

## Motion Detector

Version 1.0.1



### Packing List



Motion Detector \*1



QSG\*1




CR123A Battery\*1



Screw Package\*1

1.2.51.32.1.51.63-000

### Introduction



#### LED Pin

When it is set to 1&2, the LED turns on when alarm happens, when it is set to 2&3, the LED turns off. It is set to be 1&2 by default.

#### Sensitivity Pin

Sensitivity is high when it is set to 1&2, and low when it is set to 2&3. It is set to high sensitivity by default.

LED Indicator Status	Device Status
Red light fast flashes	Booted up or pairing with Alarm Station
Red light is on for 2s, and then turns off	Pairing succeeded
Red light slowly flashes for three times, and then turns off	Pairing failed



## About the Guide

- This quick start guide is for reference only. Minor difference might be found in user interface.
- All the design and software here are subject to change without prior written notice.
- All trademarks and registered trademarks mentioned are the properties of their respective owners.
- Please visit our website or contact your local service engineer for more information.
- If there is any uncertainty or controversy, please refer to our final explanation.

## Start to Use

### Imou App

If Imou app has added the Alarm Station, add the detector according to app prompts.

#### Note:

If the detector has paired with another Alarm Station, you can undo previous pairing by quickly clicking tamper switch for 5 times to clear the existing pairing configuration.

## Installation

